


IR Transmitter 1 to 4



INTRODUCTION

Remote controller IR (Infra Red) extender extends IR signal through HDMI cable to remote location. Say you have source devices such as cable box and blueray player in the living room, and TV in the bed room upstairs. You can change TV channel or switch to blueray pleyer on the bed without going downstairs to the living room. Transmitter with four head enables you to control four signal resource at the same time by one conector system.

FEATURES

1. Need 110513 IR receiver) and 110514 (IR adapter)
2. 1.2m default length cable with 3.5mm male plug
3. Max extension distance 300Ft (100m)
4. No external power required
5. IR function or CEC function switchable

CONNECTION DIAGRAM WITH IR EXTENSION

