

Electronic Luggage Scale

Instructions for Use



Specifications:

1. Room temperature display, (°C, °F)
 2. Zero tracking and tare function.
 3. 0.44"(11.3mm) LCD digits
 4. Low battery / over load indication
 5. Capacity: 50kg/110lb;
 6. Graduation: 10g/0.02lb
 7. Power: 1X3V Lithium cell (CR2032)
-

Key illustration:

- $\frac{\text{ON}}{\text{Z/T}}$: Switch on/off (press for 2 seconds to switch off)
UNIT : Convert between weight unit and temperature
-

Weighing:

1. Strap the webbing belt through the luggage handle, and secure the hook of the belt onto the triangle ring.
2. Press $\left[\frac{\text{ON}}{\text{Z/T}}\right]$ to switch on the scale before lifting (ensure no stress)
3. When display shows zero, press **[UNIT]** to select weight unit
4. To re-weigh: press $\left[\frac{\text{ON}}{\text{Z/T}}\right]$ to reset LCD display to zero.
5. Lift the scale gently. Make sure the scale is horizontal and balanced. LCD shows the weight of luggage. Wait for weight reading to stop and stabilize, Flash 1 time and locked. Scale will display weight reading for 60 seconds and automatically switch off.
6. When weight reading is locked, press $\left[\frac{\text{ON}}{\text{Z/T}}\right]$ to reset LCD display to zero and start new weighing. Scale will automatically switch off if idle for 1 minute.



Room temperature

1. Press $\left[\frac{\text{ON}}{\text{Z/T}} \right]$ to switch on the device, wait until LCD shows zero. Press $\left[\text{UNIT} \right]$ to view temperature (in Celsius and Fahrenheit). Press $\left[\text{UNIT} \right]$ again to revert the normal weighing mode.
2. When converting to temperature display mode, LCD shows "0.0", meaning the scale is testing temperature and will display temperature reading in 2 seconds.

To replace battery

LCD will display "Lo" when battery power is low. Replace battery as follows:

1. Hold the scale in one hand. The thumb and index finger of the other hand hold and press on the screw threads of the battery case and pull out the battery case from the slot.
2. Push corner A outwards to release the used battery.
3. To insert new battery, slide one side of new battery beneath the retainer notch B & C. Press the other side of battery till it clips underneath the corner A. Ensure to observe the polarity as illustrated in the drawing.
4. Insert the battery case back to the slot on the scale.



Battery case

Care and maintenance:

1. Wipe the scale with a slightly damp cloth. DO NOT immerse the scale in water or use chemical/abrasive cleaning agents.
2. DO NOT stress the triangle ring for long time. During travel, keep the scale away from objects with sharp ends (such as toy, stationery etc.), In case the scale is switched on frequently and consume battery power.
3. To make sure accuracy, DO NOT use this scale in strong-magnetic field.
4. Keep the scale away from babies and children to avoid danger of swallow the batteries and small components.